


ELECTRICAL SYSTEM

CONNECTS TO PC.



**Printed Circuit
Board**

NOTE
 LIGHTS
 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11 ARE ALWAYS
 ON DURING PLAY.
 1, 3, 5, AND 10 TURN
 ON/OFF DURING PLAY.

